



Device Manager Quick Start


Setp1. Open the Device Management and click “**search**” items to start broadcast search by MAC address.




Setp2. If your unit of device can be found, click the unit to login.




Setp3. If you need to copy current settings to the same type of other device, please follow the diagram below, set **Baud Rate** for example:



Setp4. If copy successfully, and then apply settings and restart as follow




Other Features



- **Default_all**

All devices restore to factory default parameters to work,the steps as follow:


- 1.Open Device Manger2.2, refer to the above **steps 1** .
- 2.Click **Tools->Default_all** , and restore to factory default parameters.
- 3.Click **Search** to browse the changed devices



- **Assign IP:**

Specifies a start IP segment, and according to the order assign IP.

1. Open Device Manager 2.2, refer to the above **steps 1**.
2. Click **Tools->Assign IP** to assign IP by subnet mask setting.
3. Click **Search** to browse the allocated IP address of serial devices.
4. Also you can use DHCP to assign IP address for all devices



- **Maintain:**

When performing maintenance, the managed device may perform a reboot,
And check the user's configuration parameters, version, etc.

1.Open Device Manger2.2, refer to the above **steps 1**

2. Click **Tools->Maintain(all)** to perform maintenance.

3.Click **Search** to browse the version information of devices

